


DIESEL LOOM 2007 449661902








BATTERY LEADS

44-80054-00 EARTH LEAD
44-80055-00 RED BATTERY LEAD
44-80053-00 BLACK BATTERY LEAD



KEY

A FUEL LEVEL SENDER
B SEAT SWITCH
C ELECTRIC CLUTCH
D FUEL SOLENOID HOLD
E FUEL PUMP
F ENGINE START SWITCH (IGNITION START)
G ELECTRIC CLUTCH SWITCH
H HEADLIGHT SWITCH
I ON SWITCH (IGNITION ON)
J PARKING BRAKE SWITCH
K HEADLIGHTS
L SWEEPER UP RELAY
M GLOW PLUG RELAY
N GLOW PLUGS
P NET UP RELAY
Q NET EMPTY ACTUATOR
R SWEEPER DOWN RELAY
S FUEL SOLENOID PULL RELAY
T FUEL SOLENOID PULL COIL
U NET DOWN RELAY
V SWEEPER LIFT ACTUATOR
W GLOW PLUG TEMPERATURE SWITCH
X SWEEPER UP SWITCH
Y DECK ACTUATOR POTENTIOMETER
Z SWEEPER DOWN SWITCH
a NET UP SWITCH
b NET DOWN SWITCH
c DECK UP RELAY
d WATER TEMPERATURE SWITCH
e OIL PRESSUE SWITCH
f DECK DOWN RELAY
g DECK LIFT ACTUATOR
h STARTER SOLENOID
i STARTER MOTOR